



Balansposities

NEOX

| Balanspositie mogelijk bij zitdiepte: | 20" | | | | 22" | | | | 24" | | | | 26" | | | |
|---------------------------------------|-----|-------|-------|-------|-------|-------|-------|-------|-----|-------|-------|--------|-------|-------|-------|-------|
| | 5" | 6" | 7" | 8" | 5" | 6" | 7" | 8" | 5" | 6" | 7" | 8" | 5" | 6" | 7" | 8" |
| D40 | ✓ | 2,3,4 | 3,4 | 4 | 2,3,4 | 3,4 | 4 | x | 3,4 | 3,4 | 4 | x | 2,3,4 | 3,4 | x | x |
| D42 | ✓ | ✓ | 2,3,4 | 3,4 | 2,3,4 | 2,3,4 | 3,4 | 4 | 3,4 | 3,4 | 3,4 | 4 | 2,3,4 | 3,4 | 4 | x |
| D44 | ✓ | ✓ | 2,3,4 | 2,3,4 | ✓ | ✓ | 2,3,4 | 3,4 | ✓ | 2,3,4 | 3,4 * | 3,4 ** | 2,3,4 | 2,3,4 | 3,4 | 4 |
| D46 | ✓ | ✓ | ✓ | 2,3,4 | ✓ | ✓ | 2,3,4 | 2,3,4 | ✓ | ✓ | 2,3,4 | 3,4 ** | 2,3,4 | 2,3,4 | 3,4 | 3,4 |
| D48 (framemaat 1) | ✓ | ✓ | ✓ | 2,3,4 | ✓ | ✓ | 2,3,4 | 2,3,4 | ✓ | ✓ | 2,3,4 | 3,4 ** | 2,3,4 | 2,3,4 | 3,4 | 3,4 |
| D48 (framemaat 2) | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | 2,3,4 | ✓ | ✓ | ✓ | 2,3,4 | ✓ | ✓ | 2,3,4 | 3,4 |
| D50 | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | 2,3,4 |
| D52 | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ |
| D54 | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ |
| D56 | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ |

* Balanspositie 2- Medium actief mogelijk vanaf framehoogte 44 cm
 ** Balanspositie 2- Medium actief mogelijk vanaf framehoogte 47 cm
 ✓ Alle balansposities mogelijk

